


Basement Heat Pump

No Cooling; Cooling mode

This chart is assuming you have 12Vdc between “B” and “Y” at the 9-pin plug at the PC board

See chart for PC Board Flash codes



!!Shock Hazard Warning!!
 Inspecting electrical components and systems risks death by electrocution as well as serious burns or other injuries to the inspector or to others.
Do not attempt these tasks unless you are properly trained and equipped.